

Garage Opener Troubleshooting Checklist

1. Test the wall button before testing remotes.
2. Check lock or vacation mode on the wall console.
3. Replace the remote battery and test close to the opener.
4. Inspect both safety sensor LEDs and clear the door path.
5. Note beeps, blink counts, or wall-panel error codes.
6. Stop if the door is heavy, crooked, off track, or spring/cable parts are involved.

Do not bypass sensors or adjust spring hardware as a DIY step.